



1. From the rear of the machine MARK THE CENTER 5" from the right side and 2 1/2" from the bottom. This will be past the float switch.

2. Drill 7/16" hole.

3. Insert overflow fitting, connect drain hose, run hose to floor drain.